

**1. Q: I've installed Windows 8 on VisionX, why can't I use my Bluetooth device after resuming from sleep mode?**

**A:** Please update the Bluetooth driver for Windows 8 from ASRock's website.

[http://download.asrock.com/drivers/all/Bluetooth/Bluetooth\\_Win8-64\\_Win8\(v8.0.0.204\).zip](http://download.asrock.com/drivers/all/Bluetooth/Bluetooth_Win8-64_Win8(v8.0.0.204).zip)

**2. Q: I want to use TRIM function for RAID. Which system supports TRIM for RAID 0?**

**A:** According to Intel documents, for a system to support Trim for RAID 0 it must meet the following conditions.

1. Please check whether your SSD supports TRIM function.
2. Intel 7-Series Express Chipset-based motherboard.
3. Windows 7 (Windows 8 will support Trim for RAID 0 in the future)
4. RAID 0 volume combined by SSD drives.
5. Intel Rapid Storage Technology software 11.0 version or later.
6. Intel SSD Toolbox 3.1.1 version or later.

**3. Q: How do I use dual monitors in Maximum 3D performance mode with a GTX690 VGA card?**

**A:** The GTX690 has two GPUs that will work together in Maximum 3D performance mode.

You have to connect your monitors to DVI\_2 & DVI\_3 which come from the same GPU.

