

OC Button Firmware Update Procedure

Please refer to the following instructions to update the firmware for the OC Button.

- Step 1. Please execute **Command Prompt** as **Administrator**.
- Step 2. Please copy the **path** of the **Z890 Taichi OCF(1.0.1.20241108)Firmware** folder.
- Step 3. Please enter "cd **path of the firmware folder**" and press ENTER to access the folder, and then execute "**Update Z890 Taichi OCF.cmd**" to update firmware.

```
Administrator: Command Prompt

Microsoft Windows [Version 10.0.26100.1742]

(c) Microsoft Corporation. All rights reserved.

C:\Windows\System32>cd C:\Users\ASRock\Desktop\Z890 Taichi OCF(1.0.1.20241108)Firmware

C:\Users\ASRock\Desktop\Z890 Taichi OCF(1.0.1.20241108)Firmware>Update_Z890_Taichi_OCF.cmd
```

Step 4. Please wait until the firmware update to complete.

If the update is successful, the screen will display as following.